

# Thickness Tolerances for Sponge Sheet

## SPONGE RUBBER CLOSED CELL

THICKNESS INCHES	TOLERANCE +/-
1/16" (.062)	.015"
3/32" (.094)	.020"
1/8" (.125)	.020"
3/16" (.187)	.025"
1/4" (.250)	.025"
5/16" (.312)	.025"
3/8" (.375)	.035"
7/16" (.437)	.040"
1/2" (.500)	.040"
5/8" (.625)	.050"
3/4" (.750)	.065"
7/8" (.875)	.075"
1" (1.000)	.082"

## SPONGE RUBBER OPEN CELL

THICKNESS INCHES	TOLERANCE +/-
1/16" (.062)	.010"
3/32" (.094)	.010"
1/8" (.125)	.012"
3/16" (.187)	.015"
1/4" (.250)	.025"
5/16" (.312)	.030"
3/8" (.375)	.030"
1/2" (.500)	.030"
3/4" (.750)	.045"
1" (1.000)	.045"

## WIDTH TOLERANCES FOR SPONGE RUBBER STRIPPING/SPLITTING

MATERIAL WIDTH (INCHES) ABOVE	MATERIAL WIDTH (INCHES) INCLUDING	TOLERANCE +/-
0"	.25"	.016"
.25"	.50"	.025"
.50"	1.00"	.040"
1.00"	2.00"	.063"
2.00"	4.00"	.080"
4.00"	8.00"	.100"
8.00"	16.00"	.125"
16.00"	32.00"	.160"



RUBBERMILL

**Disclaimer:** The information contained in this document is to be used as a guide only. RubberMill cannot guarantee the accuracy, or be held responsible for the information's end use.

**Talk to a person... not a machine! • 336-622-1680 • [www.rubbermill.com](http://www.rubbermill.com)**